

Introduction to LabVIEW for FRC

Part 1 - What you don't know you don't know

Robotics Academy

West Vancouver School District, West Vancouver



ni.com


LabVIEW Usage in Universities

110
Countries
7000+
Universities



Companies that use LabVIEW





The 4 Stages of Learning

1. Unconscious Incompetent
2. Conscious Incompetent
3. Conscious Competent
4. Unconscious Competent

Software Considerations: VEX Vs. FRC

VEX – entire 1010 team has

many (23+) robots

many (23+) programmers

many (23) GitHub repositories

FRC – entire team has

1 robot

multiple programmers

1 Github repository

How would you write code?

What changes would you need to make in how you work?

Think about it.....

Programming in a Group

1. Split up portions of code such that everyone can program efficiently.
2. Select the **Team Integrator**.
TI: combines all code written by the team into the final program.
TI: communicates with programmers to ensure all code can work together effectively.
3. Ensure each workload is realistic.
Certain portions of the project require more work than others.
For eg: **TI** typically has a larger workload.

Readme.md

What to put in Readme.md?

- **Team Members:** Names/functions/assignments
- **Descriptions** of files/folders in the GitHub Repository
- Links to **Tutorials / Resources**
- Learn **Markdown** !! (that's why its *.md file)
- For example, [Huskie Robotics](#), [FRC-Team2655](#)

A direct relationship exists between LabVIEW development style and


- Ease of use
- Readability
- Maintainability
- Efficiency
- Reliability
- Simplicity
- Performance
- Development time
- Standards
- Certifications
- Productivity

www.bloomy.com


LabVIEW Style Checklist

- Use spaces between words in a label (variable). Keep it consistent!
- Label shift registers and long wires
Eg: long wires that span the entire block diagram.
- Verify that data flows from left to right, and that wires enter from the left and exit to the right.
- Use the Bundle by Name and Unbundle by Name functions when you access clusters. Avoid using the unnamed Bundle and Unbundle functions.


LabVIEW Snaghetti Code – Messy Block Diagram



Spaghetti VI - Diagram



Spaghetti VI - Panel



And now.....

.....on to LabVIEW

- Bring up LabVIEW
- Open up a new Blank VI

Test your LabVIEW Skills.....

Easy: Write a VI for a **stopwatch**.

START button starts the timer.

STOP button stops the timer.

RESET button resets the timer.

Medium: Write a VI For a **7-segment display**

User can enter a number from 0 – 9,
and the corresponding LEDs light up

Bonus: Write a VI for a **Calculator** : + - X /

Learn Your Hotkeys

NATIONAL INSTRUMENTS LabVIEW™ Quick Reference Guide

Keyboard Shortcuts					
File		Ctrl-X	Cut object	Right Click	Display controls/ functions palette
Ctrl-N	Create new VI	Ctrl-Z	Undo last action	Shift-Right Click	Display tools palette
Ctrl-S	Save VI	Ctrl-Shift-Z	Redo last action	Ctrl-T	Tile block diagram and front panel windows
Ctrl-P	Print	Operate		Help	
Edit		Ctrl-R	Run VI	Ctrl-H	Display context help
Ctrl-V	Paste object	Ctrl-.	Abort VI		
Ctrl-U	Clean up diagram	Window			
Ctrl-Space	Activate quick drop	Ctrl-E	Display block diagram/ front panel		
Ctrl-B	Remove broken wires				
Ctrl-C	Copy an object				


Editing Tools		
Tool	Icon	Description
Show Context Help		Display the context help window
Text Settings		Change the font setting for the VI, including size, style, and color
Align Objects		Align selected objects
Distribute Objects		Space objects evenly
Resize Objects		Resize multiple front panel objects to the same size
Reorder		Reorder the layers of the objects
Clean Up Diagram		Rearrange wires and objects on the block diagram
Enter		Appears when a new value is available to replace an old value

Debugging Tools		
Tool	Icon	Description
Run		Execute the VI
List Errors		List errors that prevent the VI from running
Run Continuously		Execute the VI continuously until abort or pause is pressed
Stop		Stop VI execution immediately
Execution Highlighting		Animate data movement on the block diagram wires
Pause		Temporarily stop execution to debug a portion of the VI
Step Into		Single-step into a subVI or structure to debug it
Step Over		Execute a subVI or structure and resume single-stepping in next main function
Step Out		Execute a subVI or structure and resume single-stepping in calling VI or structure

Tools Palette		
Tool	Icon	Description
Automatic Tool Selection		Automatically choose the appropriate tool
Operating Tool		Change the value of a control or select the text within a control
Positioning Tool		Position, resize, and select objects
Labeling Tool		Edit text and create free labels
Wiring Tool		Wire objects together on a block diagram
Scroll Tool		Scroll the window without using the scroll bars
Breakpoint Tool (used for debugging)		Set breakpoints on VIs, functions, wires, loops, sequences, and cases
Probe Tool (used for debugging)		Create probes on wires and display intermediate values on a wire in a running VI
Color Copy Tool		Copy colors for pasting with the Color Tool
Color Tool		Set the foreground and background colors

Wires (Data Types)

- Other examples of wires in LabVIEW



- Floating point
- Integer
- Boolean
- String
- Array—note the wire thickness
- Cluster (group of other data types)



To Do List (recommendations)

- Documentation in [Readme.md](#) file in FIRST repository on GitHub
- Write [test programs](#) to test different robot subsystems
- Test longer programs in simulator
- [Backwards Plan](#)
 - (a) from now till Jan 5
 - (b) from Jan 6 onwards
- RoboRIO [wiring diagram](#)
- LabVIEW [Programming Style](#) Checklist